

**This series combines all features of the previous  
General Electric and Yokogawa H10 Series**

## H10PM All-in-One Leak Detector

- Detects all CFC, HFC, and HCFC Refrigerants
- Manual or automatic, auto zero balance control
- Unique sensor calibration system
- Pinpoints both small and large leaks



## H10G Manual Balance

- Detects all CFC, HFC, and HCFC Refrigerants
- Manual Balance/zero adjust control
- AC Powered
- Switchable sensitivity



## H10PA Specially Designed for Use with Automotive AC Leaks!


- All the powerful features of the H10PM, but powered from an external 12VDC source. No more worry about recharging an internal battery – simply clamp the power cable to a car battery and you are in business.
- Finding all the repairable leaks in an AC system is a promise made possible by our unique heated diode sensor technology, with sensitivity ratings exceeding SAE J1627.
- An unsurpassed value for capability and price.



SPECIFICATIONS	
Detects:	All CFC, HFC, and HCFC Refrigerants
Sensing Element:	Positive Ion Emission Heated Diode
Sensitivity:	Moving probe test per SAE Std. J1627
Alarm Sensitivity	
R-134a	Small - 0.1 oz / year Medium - 0.5 oz / year Large - 2.0 oz / year
R-12	Small - 0.05 oz / year Medium - 0.1 oz / year Large - 1.0 oz / year
Warm-up Time:	Approx. 2 minutes
Accuracy:	Exceeds SAE J1627
Probe Length:	4.5 Feet
Dimensions / Weight:	
H10PM	5.5" x 10.5" x 8.5" / 5lbs.
H10PA	5.5" x 10.5" x 8.5" / 3lbs.
H10G	2.5" x 4.5" x 8.5" / 3lbs.
Ambient operating temperature	32° to 104° F
Agency Listings:	UL File SA917, SAE J1627, CE-Mark
Power:	
H10PM	12 VDC - internal rechargeable, sealed lead acid battery 12 VDC - external battery using battery clamp / cigarette lighter plug 120 VAC - wall adapter to charge battery only 120 VAC optional wall adapter to charge-and-run unit continuously
H10PA	12VDC or optional wall adapter
H10G	120 VAC 50/60 Hz (Optional 220/230 or 240 VAC)
Leak Alarm:	Audible alarm and visible neon lamp
Response Time:	Approx. 1 sec.



## Distributed By



### Ordering Information

Part No.	Description
3015-0456	H10G Standard Leak Detector
3015-2997	H10PA Automotive Leak Detector
3015-0627	H10PM All-In-One Leak Detector

### H10P, H10PA and H10PM Accessories and Parts

Part No.	Description
3015-0895	Battery Clamp/Cigarette Adapter Assembly
3015-0119	Battery Charger
3015-0131	AC Adapter (120V)
3015-0143	AC Adapter (220V/230V)
3015-0147	AC Adapter (240V)
3015-0103	Battery for H10P and H10PM

### H10G, H10PA and H10PM Accessories and Parts

Part No.	Description
3015-0326	14" Flexible Probe
3015-0638	Standard Probe Assembly
3015-0486	Replacement Sensor
3015-0784	Maintenance Kit
3015-0864	Leak Reference Bottle
3015-0641	Clear Probe Tip
3015-0781	Tune-Up Kit
3015-0680	Rubber Probe Tip

Bacharach is a registered trademark of Bacharach, Inc.  
(c) January 2003, Bacharach, Inc., all rights reserved. All information herein is subject to verification.  
Product Catalog - 8003 05/03 10M HPC  
Printed in U.S.A.